


Product Guide



A. Battery LED

- After inserting 2 AAA batteries in the keyboard, it will blink for a second.
- If it keeps blinking in sequence, it indicates “Low Battery” so please change the batteries.

B. Power on/off switch

- Please turn ON the keyboard before using it.
- This keyboard is with “Auto-power saving mode “ function, but it is highly recommended to turn OFF the keyboard when not using.

C. ID connecting button

- The connection between the keyboard and the receiver is ready on factory default. If not, please download pairing code software on www.enermax.com .
- Install the pairing code software in your computer and start it.
- Insert the receiver into the USB port of computer, then the red light will spark in the software window.
- Press the keyboard ID connecting button. After 5 seconds, the sparking light will turn into green. Then the process is finished.

D. Battery cover

- Open battery cover and follow the remark(+, -) to putting the batteries correctly.

※Auto-power saving mode :

A.Idle Mode: When inactivity after 3 seconds (2mA@3V)

B.Sleep Mode: Idle mode occurred after 10 seconds entrance (under 50uA@3V)

※ The reinforced acryl with 7H hardness will help to reduce the chances of denting, scuffing and scratching. Care should still be taken on this product, as no coating is impervious to damage.

※ Some experts believe that long time use of any keyboard may cause any serious injury to hands, wrists, arms, neck or back. If you feel pain, numbness, weakness in these areas, see a qualified health professional.